

Waypoints

To use the Shortcuts menu:

1. Select **Shortcuts**. The Shortcuts menu appears.
2. Rotate the **Rock 'n Roller™** to the preferred application and press **ENTER**.

To mark a waypoint:


1. From the Map page, select **Shortcuts**. Rotate the **Rock 'n Roller** and select **Mark Waypoint**. The screen shows that the waypoint was successfully saved. A three-digit number is assigned to the new waypoint (your current location).
2. Select **Done** to save the waypoint. Select **Edit** to edit the waypoint properties. Select **Cancel** to delete the waypoint.

To go to a waypoint:


1. Select **Shortcuts > Where To? > Waypoints**.
2. Highlight the preferred waypoint and press **ENTER**. A green circle containing the word **Go** appears.
3. Press **ENTER** to begin navigating to the waypoint, or press **Options** to project or edit the waypoint.
4. To stop navigation, select **Shortcuts > Stop Navigation**.



Mark Waypoint on Shortcuts



Waypoint Saved




Waypoint Page

System Status

To adjust the backlight level:

1. Press and quickly release the **Power** key. The System Status page on the Colorado appears.
2. Rotate the **Rock 'n Roller** clockwise or counter-clockwise to increase or decrease the backlight.
3. Select **Back** to close the System Status page and return to the previous page.



System Status Page



NOTE: The System Status page is also a quick way to check the time, day, date, battery level, and GPS signal strength.

Map Page

To access the Map page:

1. Select **Shortcuts > Map**.
2. Select **Options** to show the Data fields, change the Data fields, or hide the soft key labels.

To zoom in and out on the Map page:

1. Rotate the **Rock 'n Roller** clockwise to zoom in.
2. Rotate the **Rock 'n Roller** counter-clockwise to zoom out.



Zoom Out View



Zoom In View

To pan across the map:

1. Press up, down, left, and right on the **Rock 'n Roller** to move the cursor on the map.
2. Select **Done** to stop panning.

Please visit www.garmin.com for additional documentation and information.

190-00751-01 Rev. A © 2007 Garmin Ltd. or its subsidiaries
Printed in Taiwan

GARMIN

Quick Start Guide

Colorado™ Series



all-terrain GPS navigator

Overview


WARNING: See the *Important Safety and Product Information* sheet in the product box for product warnings and other important information.



Startup

Using the Rock 'n Roller™

- Rotate the **Rock 'n Roller** to move up and down menu lists. You can also move through the lists by pressing up, down, left, and right.
- Press **ENTER** to make all selections on the Colorado.
- Press up, down, left, and right on the **Rock 'n Roller** to pan the map.



Using Soft Keys


- The **Left soft key** and the **Right soft key** are used to access specific options that appear on the soft key labels.
- When labeled, press the soft keys to show available menus.
- If a soft key is not labeled, it is not available for that specific page.



Additional Functions

To install batteries:

1. Remove the battery cover by lifting the latch and sliding the cover off the Colorado.
2. Insert the batteries, observing the diagram molded into the battery compartment.
3. Replace the battery cover by sliding it back onto the Colorado and fastening the latch.



To attach the carabiner clip:

1. Position the carabiner clip in the slots on the mounting spine of the Colorado.
2. Slide the clip up until it locks in place.
3. To remove the carabiner clip, lift the bottom of the clip and gently push down on the carabiner clip until it releases.



Basic Operation

First-time startup:

1. Press and hold the **Power** key until the Garmin logo appears on the screen.
2. Starting the Colorado the first time requires you to choose your language, time zone, and Daylight Saving mode. When the Language page appears, highlight the preferred language and press **ENTER**.
3. Highlight the preferred time zone and press **ENTER**.
4. Highlight the preferred Daylight Saving mode and press **ENTER**. The Colorado then shows the Map page.
5. Take your Colorado to an area with a clear view of the sky.
6. If the cursor on the Map page is blinking, wait for the Colorado to collect satellite data and establish its current location.
7. To turn off the Colorado, press and hold the **Power** key.




NOTE: You must be outdoors with a clear view of the sky to acquire satellites.



Language



Time Zone



Daylight Saving